

**Procedure to check play of
lines of ETCW gearbox.**

1- Preparation

To check the play, you need to extract external bearing rings from rear cover. For this you need an extractor, a heater plate and **GLOVES**.



How to operate :

- Put the cover on the heater plate
- When it is hot, help you with the extractor to extract bearings

2- Primary and secondary lines gap

initialize your control means '0' on primary 6th gear face.



2- Primary and secondary lines gap

Measure gap G between primary and secondary lines on secondary 6th gear.




Gap G

If the value exceeds 0.5mm, adjusting shim $\varnothing 61 \times \varnothing 52$ for primary line or $\varnothing 71 \times 60$ for secondary line should be added on clutch casing side .


3- Primary and secondary lines play

When the bearings are cold, put them on the lines and initialize your control means '0' on cover contact surface.




3- Primary and secondary lines play

Measure dimension P1 on primary line (gearbox side)




3- Primary and secondary lines play

Measure dimension S1 on secondary line (gearbox side)




3- Primary and secondary lines play

initialize your control means '0' on gearbox contact surface.



3- Primary and secondary lines play

Measure dimension S2 on secondary line (cover side)



Dimension S2


Secondary line play = $S2 - S1$

For example here it is $11.54 - 11.32 = 0.22\text{mm}$

If the value exceeds 0.4mm, adjusting shim $\varnothing 71 \times \varnothing 60$ should be added on cover side.

3- Primary and secondary lines play

Measure dimension P2 on primary line (cover side)



Dimension P2

Primary line play = $P2 - P1$

For example here it is $11.11 - 10.79 = 0.32\text{mm}$

If the value exceeds 0.4mm, adjusting shim $\varnothing 61 \times \varnothing 52$ should be added on cover side.

4- Barrel axial play

initialize your control means '0' on barrel through sensor hole.



4- Barrel axial play

Move the barrel on upper position and measure barrel play B.



If the value exceeds 0.3mm, adjusting shim $\varnothing 51 \times \varnothing 47$ should be added on cover side .

5- Procedure to assemble external bearing rings in the cover

1- Put the cover on heater plate



2- Put glue Loctite 648 on external bearing rings



4- Procedure to assemble external bearing rings in the cover

3- Put the rings in the cover (if the cover is hot enough, the rings engage freely).

